

Max-E LED Colour Code

PESS ENERGY – Max-E

ICON	LED COLOURS	DESCRIPTION
	White	1. All 10 LEDs “breathe” (intensity progressively increases and decreases) : system self-test.
		2. In standby, the LEDs indicate the battery level (each LED = 10%).
		3. While charging, the LEDs blink sequentially. E.g. : at 70%, LEDs 1 to 7 blink.
		4. Fully charged : all LEDs solid white.
	Green	While discharging, the LEDs indicate the remaining level (each LED = 10%).
	Yellow	1. LED 1 turns yellow when the level is between 1% and 10%.
		2. LEDs 5 and 6 turn yellow to indicate an internal warning.
	Red	1. LED 1 solid red : battery at 0%, output disabled.
		2. All LEDs solid red : system fault. Restart the unit. If the fault persists, contact after-sales support (SAV).
		3. LEDs 1, 3, 5, 7, 9 solid red : equipment locked. Contact after-sales support (SAV).

Press the power button to switch the equipment on or off.

Internal document – EN version